



STOCK NO.	DESCRIPTION
KA13250-RK	15 Amp Circuit Breaker Kit (replaces fuseholder)
PA-926-000	Air Vent Assembly
KA18144-000	Thermostat Assembly
B-2921-000	Fusible Link
E-PROMKIT	E-prom Upgrade for PC Board
A-3354-000	Chamber Fittings Seal Package
A-3357-000	Topcover Assembly (Serial Number required when ordering)
A-3264-000	PC Board Assembly (Serial Number required when ordering)
KA13206-000	SES-2000 2.0 Amp Fuse -for PC Board
*A-3184-000	Door Sealing Gaskets -Package includes 3 different seals
KC13311-001	Heater
A-3897-000	Water level Sensor
A-3338-000	Safety Relief Valve Assembly , 38 psig.
BX-267	Shipping Box with
BX-267-001	Foam Inserts for Shipping Box see above
SES-Video	SES-2000 Cleaning Video



STOCK NO.	DESCRIPTION
SES2000E	
1. PB-138-025	"C" Clip
2. PB-123-010	Bowed Washer
3. A-2959-000	Anti-Friction Washer
*4. A-3184-000	Door Sealing Gaskets -Package includes 3 different seals
5. B-2915-000	Door Clamp Disc
6. PB-892-000	Silicone Washer
7. A-2961-000	Stainless Steel Washer
8. PB-891-000	Airtight Nut
SES2012E	
*4. A-3314-000	Door Sealing Gaskets -Package includes 2 different seals
6. PA-1037-001	Silicone Washer
7. PB-103-050	Stainless Steel Washer
8. PA-1042-000	Airtight Nut

* We recommend that all door gaskets be changed at the same time; therefore, a package of 1 each of the different seals is supplied.




STOCK NO.	DESCRIPTION
1. PC-882-000	Pressure Gauge
*2. A-3316-000	Circuit Board with Steam Temperature Sensor- Calibrated
KA13206-001	PC Board Fuse- 2.0 Amp
3. KA16805-001	Power Switch (On/Off)
*4. KA16655-000	Transformer
5. A-3355-000	Solid State Relay
*6. KA18144-001	Thermostat Assembly
22. PB-905-000	Thermocouple Entry Port (Self-Seal Test Plug)

NOT SHOWN

A-3224-RK	100% Drainable Reservoir
A-3353-000	Chamber Fitting Seals Package
SES-VIDEO-E	SES 2000E Cleaning/Maintenance Video Tape
PB-103-049	Sealing Washer, Copper
A-2960-000	Sealing Washer (Safety Relief Valve and H₂O inlet)
A-3377-000	Water Inlet Fitting Assembly

NOTE: Parts marked with an asterisk (*) are different for the SES-2000 model. REFER TO PAGE 26.




STOCK NO.	DESCRIPTION
7. A-3701-000	Water Fill Solenoid Valve
8. A-3701-000	Discharge Solenoid Valve
PA-1104-000	Solenoid Plunger Only
9. KA13200-010	Fuse, .8 Amp
KA12423-001	Fuse Holder
10. KC13311-000	Heater Element Coil
11. KB19529-002	Air Vent Valve Solenoid Assembly
12. A-3338-000	Safety Relief Valve Assy., for S/N 3500-3999
A-3338-001	Safety Relief Valve Assy., (40 psig units only) for S/N 4000 & above
13. KA16804-000	Door Microswitch
14. C-942-000	Pressure Door Interlock Assembly
15. B-2921-000	Thermal Fuse (Fusible Link) Assembly
17. A-3313-000	Water Level Sensor Assembly
18. PA-977-000	Discharge Filter
20. KA13250-RKE	Circuit Breaker, 15 Amp
21. N/A	Steam Temperature Sensor


NOT SHOWN

A-3184-000	Door Sealing Gaskets
PB-945-000	Drain Tube Assembly
PA-1055-000	Drip Tray
PC-880-000	Small Round Reservoir Lid-Gray
PB-878-000	Reservoir Sealing Gasket Ring
C-940-000	Tray (Small)
PB-1114-000	Tray Handle
KA18160-000	Calibrated Temperature Probe

NOTE: Parts marked with an asterisk (*) are different for the SES-2000 model. REFER TO PAGE 26.



STOCK NO.	DESCRIPTION
1. PC-882-000	Pressure Gauge
2. A-3317-000	Circuit Board with Steam Temperature Sensor- Calibrated
KA13206-001	PC Board Fuse- 2.0 Amp
3. KA16806-001	Power Switch (On/Off)
4. KA16655-003	Transformer
5. A-3367-000	Solid State Relay
6. KA18144-001	Thermostat Assembly
16. PB-878-000	Reservoir Gasket Sealing Ring
19. A-3315-000	Drain Tube Assembly
NOT SHOWN	
KA18160-000	Calibrated Temperature Probe
PB-103-049	Sealing Washer, Copper
A-2960-000	Sealing Washer (Safety Relief Valve and H₂O inlet)
PA-1055-000	Drip Tray
C-1052-000	Tray (Large)
PB-1114-000	Tray Handle
C-940-000	Tray (Small)
A-3377-001	Water Inlet Fitting Assembly
A-3353-000	Chamber Sealing Package



STOCK NO.	DESCRIPTION
7. A-3701-000	Water Fill Solenoid Valve
8. A-3701-000	Discharge Solenoid Valve
PA-1104-000	Solenoid Plunger Only
9. KA13201-009	Fuse, .2 Amp
KA12423-001	Fuse Holder
10. C-1023-000	Heater Element Coil
11. KB19529-001	Air Vent Valve Solenoid Assembly
12. A-3338-000	Safety Relief Valve Assembly
13. KA16804-000	Door Microswitch
14. C-942-000	Pressure Door Interlock Assembly
15. B-2921-000	Thermal Fuse (Fusible Link) Assembly
17. A-3313-000	Water Level Sensor Assembly
18. PA-1043-000	Discharge Filter
21. N/A	Steam Temperature Sensor
22. PB-905-000	Thermocouple Entry Port (Self Seal Test Plug)